

Savannah River
NUCLEAR SOLUTIONSSM
FLUOR DANIEL • NORTHROP GRUMMAN • HONEYWELL


TLND Correction Factor Evaluation using the ROSPEC

David Wagoner
Health Physicist
Savannah River Nuclear Solutions, LLC

Savannah River Chapter of the Health Physics Society
16th Annual Technical Seminar
April 20, 2012

Background

- On June 8, 2007 10CFR835 was amended to reflect recommendations given in ICRP 60
 - Updated organ/tissue weighting factors
 - Updated internal dosimetric models
 - Changed terminology
 - Updated Appendix A, C, and E
 - Introduced radiation weighting factors, operational, and protection quantities
 - Q(L)-L relationship was revised





2

Background

- *Protection quantities* – Regulatory dose limits
 - Effective dose (E)
 - Equivalent dose (H_T)
- *Operational quantities* - Measureable quantities used to ensure compliance with dose limits
 - Personal dose equivalent $H_p(10)$
 - Ambient dose equivalent $H^*(10)$
 - Directional dose equivalent $H'(10, \Omega)$

All Radiation Types are not Equal!

- Some types of radiation are more damaging per unit absorbed dose than others
 - This is due to Linear Energy Transfer (LET)
- Quality Factors (ICRP 26) and Radiation Weighting Factors (ICRP 60) were developed to account for the effects of higher LET radiation types
- For neutrons this relationship is energy dependent!



Personnel Monitoring

- Radiological workers with the potential for neutron exposure are issued a 912 Thermoluminescent Neutron Dosimeter
 - 4 $\text{Li}_2\text{B}_4\text{O}_7$ phosphors shielded in various configurations with cadmium and tin
 - 3 of the 4 phosphors are enriched ^6Li
 - Measures neutron exposure to personnel via the albedo effect
- We need to determine a factor that accounts for the entire neutron spectrum

Rotating Neutron Spectrometer (ROSPEC)



Rotating Neutron Spectrometer (ROSPEC)


- 6 gas filled proportional detectors affixed on a rotating platform

Counter Name	Diameter (Inches)	Fill Gas	Fill Gas Pressure (atm)	Energy Range (MeV)
Thermal	2	Helium	0.08	<1E-6
Epi-thermal	2	Helium	0.5	1E-6 – 1E-2
SP2-1	2	Hydrogen	0.75	0.05 - 0.25
SP2-4	2	Hydrogen	4	0.15 - 0.70
SP2-10	2	Hydrogen	10	0.40 - 1.50
SP6	6	P10	5	1.20 - 4.50

Rotating Neutron Spectrometer (ROSPEC)

- Software compiles results from each detector to generate a neutron spectrum
- Measures neutron fluence for each energy bin and calculates $H(\max)$, $H^*(10)$, and $H_p(10)$ using fluence to dose conversion factors.
- $E(AP)$ is calculated with a separate program that uses the neutron spectra generated by the ROSPEC

ROSPEC Neutron Spectrum




Method

- Empirically measure neutron spectra with the ROSPEC in various neutron fields across the site



Method


- Setup a phantom with TLND's and EPD-N2's in the same location as the ROSPEC




Method

- Measurements were performed in KAMS, H-Canyon, HB-Line, and E-Area
- Compare the TLND and EPD-N2 results with the personal dose equivalent calculated by the ROSPEC software
- The ratio of the personal dose equivalent, $H_p(10)$, and the average TLND response, $H^*(10)$, is equal to the neutron correction factor

Measured Neutron Spectra



Measured Neutron Spectra



Measurement Results

- Average facility correction factor is 2.36
 - For conservatism, a correction factor of 2.5 was implemented site wide
- ROSPEC/EPD-N2's ratio was 0.93
 - The response algorithm was adjusted to account for this difference

Location	Facility Correction Factor
E-Area Pad 5 – 1	3.48
E-Area Pad 5 – 2	1.91
E-Area Pad 5 – 3	3.11
E-Area Pad 5 – 4	2.68
E-Area Pad 5 – 5	1.43
E-Area Pad 15 – 1	2.04
E-Area Pad 15 – 2	3.35
H-Canyon	1.28
HB-Line	3.29
KAMS – 1	1.98
KAMS – 2	2.01
KAMS – 3	2.04
KAMS – 4	2.03

Conclusions

- Based on the measurement results, the neutron correction factor for the Savannah River Site is 2.5
- EPD-N2 response algorithms were adjusted
- Neutron spectral measurements should be performed anytime there is a change in the neutron source term or on a periodic basis to verify the neutron spectra